

Safety and FCC Information

	<p>CAUTION</p> <p>RISK OF ELECTRIC SHOCK DO NOT OPEN</p>	
<p>CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK: DO NOT REMOVE SCREWS, COVERS OR THE CABINET NO USER SERVICE PARTS INSIDE REFER SERVICE TO QUALIFIED SERVICE PERSONNEL</p>		



The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of un-insulated "dangerous voltage" with the products enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the users to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of electric shock, fire, etc:

1. Read these instructions.
2. Keep these instructions.
3. Heed all Warnings.
4. Follow instructions.
5. Do not use this apparatus near water or in rain.
6. Clean only with dry cloth. For stubborn stains, use a soft cloth dampened with a weak solution of mild detergent and water. Dry the

apparatus immediately afterwards with a clean cloth. Do not use abrasive cloth, thinners, alcohol, or other chemical solvents, because they may damage the finish or remove the panel lettering.

7. Do not block any ventilation openings. The ventilation shall not be impeded by covering the ventilation openings with items, such as newspaper, table cloth, curtains, etc.
8. Do not install near any heat sources such as radiator, heaters, stove or other apparatus (including amplifier) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wider blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they are exit from the apparatus. If the power cord is damaged, it must be repaired by a qualified repairer.
11. Only use attachments accessories specified by the manufactures.
12. Unplug this apparatus during lightning storms or when unused for long period of time.
13. If the apparatus comes with an AC adaptor, make sure the adaptor is not covered by cloth or soft material, keep it uncovered all the time

14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. The apparatus shall not be exposed to dripping or splashing and no objects filled with liquids.
16. For the handheld or lapel microphone, do not use them under the storm weather, especially in the rain and wet, it might get thunder shock.

FCC

Transmitters: Certified to FCC Part 74 Certified by FCC approved labs.
Note: This equipment has been tested and found to comply with limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interferences in a residential installation. This equipment generates uses and can radiate radio channel energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not cause harmful interference to radio or television reception, which can be determined by turning the equipment off an on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Increase the separation between the equipments and receivers that you might use together. The farther, the better.
2. Try to connect the equipment into an outlet on a circuit that is difference from the receiver used.
3. Extend the antenna or rotate the antenna to get the best result.
4. Consult certified or experienced technician to help.

Notes:

An FCC ministerial license may be required to operate this equipment in certain areas. Consult your national authority for possible requirements. Refer to the FCC 47 C.F.R.§ 74.832 for details.

This radio equipment is intended for use in musical professional entertainment and similar applications.

WARNING:

Change or modifications not expressly approved by Hisonic Inc for compliance could avoid the user's authority to operate the equipment. This device compliance with Part 15 of the FCC, operation of this subject to the following conditions: (1) this device may not cause interference, and (2) this device must accept and interference that may cause undesired operation of the equipment.

For service and information, please contact Hisonic International Inc.

5185 Cliffwood Drive
Montclair CA 91763
USA: 909 628 6088,
Fax: 909 628 7999
Website: www.hisonic.net